




iPhone 7 Battery Disconnection

Prereq to disconnect the battery in an iPhone 7 to safely repair or replace internal components.

Written By: Evan Noronha




INTRODUCTION

Prerequisite guide for disconnecting the battery connector.

TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
 - [P2 Pentalobe Screwdriver iPhone](#) (1)
 - [iOpener](#) (1)
 - [Suction Handle](#) (1)
 - [Spudger](#) (1)
 - [Tri-point Y000 Screwdriver Bit](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Battery Disconnection



- Remove the following tri-point Y000 screws from the lower connector bracket:
 - Three 1.2 mm screws
 - One 2.4 mm screw

Step 2



- Remove the lower connector bracket.

Step 3



- Use the point of a spudger to lift the battery connector out of its socket on the logic board.
- ⓘ Bend the connector cable up slightly to prevent it from making contact with the socket and providing power to the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-22 05:18:44 PM.